

**MARKING**

Place the template against the door and the frame soffit and mark all the holes on the inside of the door.

**DRILLING**

1) Drill the following holes:

Hole Size Note

A 1/4" Through the door

(4 holes)

A Enlarge exterior to 3/8"

B 5/8" Through the door

C 1" Through the door for RHR

D 5/8" Inside Only (LA/LD, LS Lever Trim only)

E 7/16" Inside Only (4 holes)

**TMP4945-LEV TRIM MARKING TEMPLATE - RHR  
FOR RIGHT HAND REVERSE BEVEL DOORS**

**A Note About Templates:**

Any reproduction of this template, via fax, photocopy or digital transmission, renders it **Not To Scale**.

