

# TMP4820-TA6-FL

Place this on the inside of door.  
Line-up dashed lines with lines prepared on the door as per  
the installation instructions.  
Mark center of holes A, B & C as noted below and drill.



MP Police Lock Marking Template  
Template 48: for use with 4800 Series

